





Preparing a Door Frame for Future Wired Hardware

Single Door - Three FrameFrog Kit
Model No: FRG1L2S-001

EH3 - Electric Hinge



EPT3 - Electric Power Transfer



Conduit from FrameFrogs to the ceiling
Conduit connecting FrameFrogs within frame

Recommended Frame Preparation

- Electric Hinge Prep at Center Hinge (3/4" Hole for wires)
- 4.875" x 1.25" DPS Prep in Head with flush cover plate
- Standard Strike Prep
- Omit metal back box (mortar and dust boxes) wherever FrameFrog is installed

Implications for this Layout

- Most flexible configuration with many hardware options available at the strike
- Committed to Electric Hinge for powering the lock
- EPT is not an option
- Adds cost of DPS prep only

Recommended Frame Preparation

- 9" Long EPT Prep between hinges
- 4.875" x 1.25" DPS Prep in Head with flush cover plate
- Standard Strike Prep
- Omit metal back box (mortar and dust boxes) wherever FrameFrog is installed

Implications for this Layout

- Flexible configuration with limited space for some hardware options at the strike
- Committed to EPT for powering the lock
- Electric Hinge is not an option
- Adds cost of DPS and EPT prep

EH3











EPT3

Select the box to indicate the configuration to use for frames without electrified hardware



Single Door Kit Contents

Model No.
FRG1L2S-001

FrameFrog Long FRG4L	1	
FrameFrog Short FRG4S	2	
1/2" PVC Conduit - 40" Long	3	
1/2" PVC Sweep elbows - 4" R	2	
Mounting tabs (FrameFrog Short)	6	
PVC connectors	1	
1/2" EMT connector	1	
3/4" EMT connector	1	
Threaded 1/2" PVC Connector	1	
QR code door labels	1	

2023.2

Common Configurations

Consult Hardware Specialist For Other Configurations And Implications